



INSTALLATION

ISO-FLAME GRIPS 6260

FITS: ALL HARLEY-DAVIDSON® MODELS WITH DUAL CABLE THROTTLE CONTROLS

PART #	INCLUDED
606260	1 Pair of ISO-Flame Grips Assembled
400670	1 Adhesive, RP Cyanoacrylate Gel 3 Gram Tube
306260	1 Installation Instructions

THANK YOU FOR CHOOSING KURYAKYN!

CAUTION!

Read and follow all label warnings on the adhesive container. We recommend placing a clean rag over painted or chromed surfaces to protect these finishes from glue drips. Work carefully.

PROCEDURE – LEFT SIDE

STEP 1 Remove the existing grip. One method of removing the stock left side grip is to carefully slice the grip lengthwise down to the handlebar, and then around the grip where it meets the switch housing. Peel the grip from the bar. Completely sand all grip and glue residue from the handlebar. Clean the exposed bar completely with solvent. Wipe the inside of the rubber grip inserts completely clean with solvent.

NOTICE

This adhesive will set up **IMMEDIATELY** in the absence of air. If you hesitate even for an instant while sliding these grips into place, the grip will bond permanently in that location.

STEP 2 Pre fit the grip on the bar so you can determine the desired position. Apply glue in various places inside of the grip. You will use the entire tube of glue.

STEP 3 Using a twisting motion, slide the grip into your desired installed position. Push in (or squeeze) on the outer rubber starting at the end to ensure glue contact.

PROCEDURE – RIGHT SIDE

NOTE

We suggest consulting your service manual for additional instruction concerning this procedure.

STEP 4 See PIC.1 Roll or slide the rubber cable adjustment covers back so the adjusters are exposed. Make a reference mark on each section of exposed threads, or at least make a mental note of how much thread is exposed on each adjuster - this will be helpful when you re-adjust the cables. Using your 3/8" open-end wrenches loosen the lock nut on the adjuster and collapse it (shorten the cable housing) as far as you can - this provides maximum cable slack.



-cont.-

6260-21HD-0605

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.

kuryakyn.com



STEP 5 Separate the switch housings.

STEP 6 See [PIC.2](#). Rotate the cable so it points directly away from the throttle sleeve and slide the cables out of the sleeve. (Careful, don't lose the small brass ferrules on the cable ends - they're not attached.)

STEP 7 Remove the existing grip from the handlebar. This is a good time to lubricate your throttle and idle cable. Be careful not to knock the small crescent shaped nylon "shoe" off of the thumbscrew in the bottom of the switch housing - this is the throttle lock device. If the shoe is knocked loose, it can wedge against the throttle sleeve and cause the throttle control to stick.

STEP 8 Install the ISO-Grip in the same manner as the stock grip was removed. Double check to be sure the throttle friction shoe is in place on the thumbscrew.

STEP 9 Re-assemble the switch housing.

STEP 10 Adjust the throttle and idle cables. (Refer to STEP 4.) The cables should have a very small amount of slack, and still allow the carb to reach wide open throttle. Be certain the throttle cannot stick in any position. Tighten the locknuts against the adjusters and replace the rubber covers.



Ride On!